

Dräger X-plore 3300/3500 Half Masks



ST-17-2003

Experience a new dimension of comfort and safety in respiratory protection: The Dräger X-plore Series. Bearing in mind today's requirements for modern PPE, Dräger Safety has worked together with users from industry and the skilled professions to develop a new line of twin-filter respirators. It very successfully combines practicality of use with comfort. The use of new materials coupled with a modern, attractive design guarantees maximum comfort and user acceptance.

Wherever respiratory protection is needed, e.g. at chemical and steel plants, automobile and shipping industry, maintenance, utilities supply and disposal, Dräger X-plore half masks can provide you a perfect solution.

helmet. The innovative X-guided strap-system distributes weight evenly and the „swept-back“ design allows for a perfect fit under welding shields and visors.

Choose from either the low maintenance, economical Dräger X-plore 3300 version or the very comfortable, durable and high-quality Dräger X-plore 3500 version for long-term, demanding tasks.

Dräger X-plore half masks are available in three sizes, ensuring a great fit for different face types. Equipped with a safe and easy to use bayonet connection they are compatible with the extensive Dräger X-plore filter range.

Major features include the “FlexiFit” head cradle, almost unnoticeable under a safety

helmet. Discover the benefits of Dräger X-plore for yourself.



ST-286-2002

Dräger X-plore 3300. The low maintenance, economical half mask.



ST-881-2002

Dräger X-plore 3500. The very comfortable and robust half mask for long-term demanding tasks.

FEATURES & BENEFITS

Easy and safe handling	High level of user safety.
“FlexiFit” head cradle	The new head cradle provides an excellent fit for any head, also under safety helmets.
“Low profile”-design	The swept-back design ensures an optimal field of vision and fits well under protective visors.
Strap System	Innovative X-guided strap system ensures an even weight distribution. Easy to adjust for a perfect fit.
Flexible nose section	Gives more secure seal in the most critical area. Great compatibility with safety glasses and goggles.
Bayonet connector	Easy and secure filter attachment. Both filters are inserted in a top-down direction.

Special for the Dräger X-plore 3500:

New material	Mask body made of “DrägerFlex” material: hypoallergenic, free of silicone, extremely comfortable, and excellent durability.
“Slide down” harness	By undoing the neck hook, the mask can be removed without removing e.g. a safety helmet. The inner mask faces the body and remains protected.

TECHNICAL DATA

Material of mask body	Dräger X-plore 3300: Soft-TPE – friendly to the skin, comfortable to wear, lightweight, translucent gray Dräger X-plore 3500: "DrägerFlex" – very friendly to the skin, hypoallergenic, extremely comfortable, silicone-free, robust, black
3 sizes	small (S), medium (M), large (L)
Filter connection	Two side-positioned bayonet connectors for use with the Dräger X-plore filter range
Weight	approx. 95 grams
Approvals	NIOSH 42 CFR 84
Maintenance	Spare parts available for Dräger X-plore 3500
Extras	"Slide down" harness system and resealable storage bag (with Dräger X-plore 3500)

ORDER LIST

Dräger X-plore 3300 half mask	Small	R 55 331
	Medium	R 55 330
	Large	R 55 332
Dräger X-plore 3500 half mask (with "slide down" harness and storage bag)	Small	R 55 351
	Medium	R 55 350
	Large	R 55 352
Accessories		
	Blue Nylon bag with drawstring	40 55 785
	Alcohol-free mask wipes	40 53 845
	AirKem A33 disinfectant (40 pks)	40 54 085
	AirKem A33 disinfectant (1 gallon)	40 56 523
	Portacount Test Adaptor Set	67 38 044

The Dräger X-plore filter series offers an extensive range of particulate, gas & vapor, and combination filters and cartridges (see separate data sheet).



SUBSIDIARIES

CANADA

Dräger Canada Ltd.
Mississauga, Ontario L5N 6P9
Tel +1 905 821 8988
Fax +1 905 821 2565

USA

Draeger Safety, Inc.
Pittsburgh, PA 15275
Tel +1 412 787 8383
Fax +1 412 787 2207

MEXICO

Draeger Safety S.A. de C.V.
Querétaro, Qro México
Tel +1 412 787 8383
Fax +1 412 787 2207

Dräger Safety AG & Co. KGaA

Revalstrasse 1
23560 Luebeck, Germany
Tel +49 451 882 0
Fax +49 451 882 2080
www.draeger-safety.com