

X-plore 5500 Full Face Mask

Experience a new dimension in respiratory protection:
The Dräger X-plore Series

Wherever complete respiratory and eye protection are required, the X-plore 5500 offers you comfort and safety.

The X-plore 5500 full face mask is designed on the basis of proven, reliable technology. The double-layer face seal with triple sealing action ensures reliable protection and a secure, leak-free seal regardless of your face shape.

Other highlights include the easily adjustable head harness for quick and secure donning and doffing of the mask. The large, durable visor and the "swept-back" low profile design provide an unobstructed, wide field of vision.

The X-plore 5500 is available in one universal size to fit different face sizes. Equipped with a safe and easy to use bayonet connection it is compatible with the extensive X-plore filter range.

Discover the benefits of Dräger X-plore for yourself!



Features & Benefits

Face seal	Double-layer face seal with triple sealing action provides reliable protection and a secure fit for various face types.
Bayonet connection	For easy and secure filter attachment. Both filters are inserted in a top-down direction.
"Low profile" design	The swept-back design ensures an optimal field of vision and even weight distribution with superb freedom of movement.
Lens	Excellent, wide field of vision. Extreme chemical, thermal, and mechanical resistance.
5-point harness	Quick and easy to don without hair entanglement.
Universal size	Perfect fit for all sizes, ease of storage and spare parts handling.

Technical data

Mask body	EPDM with high ageing resistance, extremely hypoallergenic
Visor	Polycarbonate with wide field of vision
Filter connection	Two side-positioned bayonet connections for use of the X-plore filter range
Weight	approx. 540 g
Approvals	EN136 Cl. 2 with CE mark and NIOSH
Maintenance	Spare parts available

Order list

X-plore 5500 full face mask		R 55 270
Universal size		
Accessories	Spectacle Kit (frame and holder)	R 51 548
	Mabox II carrying box	R 54 610
	Wikov V mask box	R 51 019
	Lens cover (set of 25)	R 25 355
	"Klar Pilot" gel (anti-fogging gel for visor)	R 52 560
	Daisy Quick wipes	R 54 134

The X-plore filter series offers an extensive range of particulate, gas and vapour, and combination filters and cartridges (see separate data sheet).

Dräger Safety AG & Co. KGaA

Revalstrasse 1
D-23560 Luebeck
Germany
Tel. +49 451 882 - 0
Fax +49 451 882 - 20 80
www.draeger-safety.com

Draeger Safety UK Ltd.

Ullswater Close
Kitty Brewster Industrial Estate
Blyth, Northumberland, NE24 4RG
United Kingdom
Tel. + 44 1670 352891
Fax + 44 1670 356266

Draeger South Africa (Pty) Ltd.

Dräger Building
St. Peter's Square
Cnr. Waterford Place & Witkoppen Rd.
Kleve Hill Park/Sandton 2146
RSA
Tel. + (0027) 11/ 465 99 59
Fax + (0027) 11/ 465 69 53

DrägerService

Dräger equipment must always be fully operational and safe. DrägerService offers a regular inspection service and is quickly available in the event of malfunction. Your equipment will be repaired and back in operation as quickly as possible. Dräger-Service facilitates the vital flow of information between client and manufacturer.

Dräger Expertise

Since 1889, Dräger has had an outstanding reputation for solving problems in the field of human breathing. Dräger has been deeply involved in the handling of gases, in particular hazard protection and the saving of life in medical and industrial emergencies. Many of the company's 9500 employees are active in research and innovation to ensure that the latest techniques and scientific advances are fully tested before their inclusion in new equipment.

**Dräger Worldwide**

The Dräger sales and service organisation is spread throughout the world. It comprises more than 25 subsidiaries and associated companies to ensure that Dräger is always within easy reach of its clients and in close contact with all important markets. Dräger's ever increasing market share demonstrates the company's international competitiveness and strength.

Dräger has subsidiaries in the following countries: Australia, Austria, Belgium, Bulgaria, Canada, China, Croatia, Czech Republic, Denmark, France, Great Britain, Hungary, Indonesia, Italy, Japan, the Netherlands, Norway, Romania, Singapore, Slovenia, Slovakia, South Africa, Spain, Sweden, Switzerland, Thailand, Yugoslavia, USA. Additionally, Dräger is widely represented in Central and South America, Africa, the Middle East, the Far East and Eastern Europe.

Quality and Environmental Management

Our mission includes the continuous improvement of our Quality and Environmental Management Systems in accordance with ISO 9001 and ISO 14001.